

CellOx 325



Dissolved oxygen sensor

Copyright


© Weilheim 2002, WTW GmbH & Co. KG
Reprinting - even as excerpts - is only allowed with the explicit written authorization of WTW GmbH & Co. KG, Weilheim.
Printed in Germany.

Cellox 325 - Contents

1	Overview	20
2	Safety	21
3	Commissioning	21
4	Measuring / Operation	22
4.1	Calibration	22
4.2	Measuring	22
4.3	Storage	22
5	Maintenance, cleaning, replacement	23
5.1	General maintenance instructions	23
5.2	Exterior cleaning	23
5.3	Changing the electrolyte and membrane head	24
5.4	Cleaning the electrodes	26
5.5	Checking the sensor for freedom from zero-current	28
5.6	Disposal	29
6	What to do if... ..	29
7	Technical data	30
8	Wear parts and accessories	32

1 Overview

Construction



- 1 WP 90 membrane cap (filled with electrolyte solution)
- 2 Shaft
- 3 Connection head
- 4 Gold working electrode (cathode)
- 5 Insulator
- 6 Lead counter electrode (anode)
- 7 Ventilation area
- 8 Temperature sensor and auxiliary electrode

Recommended fields of application

- On site measurements in rivers, lakes and wastewater
- Applications in water laboratories
- BOD measurements

2 Safety

This operating manual contains special instructions that must be followed during the operation of the Dissolved Oxygen (D.O.) sensor.

Always keep this operating manual in the vicinity of the sensor.

Special user qualifications

The membrane cap of the D. O. sensor is filled with a small amount of an alkaline electrolyte solution. All maintenance work that requires dealing with the electrolyte solution must only be carried out by persons who are familiar with the safe handling of chemicals.

General safety instructions

The individual chapters of this operating manual use safety labels like the one below to indicate danger:



Caution

indicates instructions that must be followed precisely in order to avoid slight injuries or damage to the instrument or the environment.

3 Commissioning

Scope of delivery

- D. O. sensor CellOx 325, filled with electrolyte solution and operable
- 3 exchange membrane caps WP 90
- Calibration and storage vessel, OxiCal®-SL
- Operating manual



Note

The membrane cap that is mounted on the sensor for delivery serves mainly as a transport protection. Depending on the duration of the transport and storage period, it may have a shortened operational lifetime. If the measuring system cannot be calibrated (error message on the instrument), please proceed according to section REPLACING THE ELECTROLYTE SOLUTION AND MEMBRANE CAP.

Getting the sensor ready for measuring

Connect the sensor to the measuring instrument. The sensor is immediately ready to measure. It is not necessary to polarize the sensor.

4 Measuring / Operation

4.1 Calibration

**Note**

For calibration, please refer to the operating manual of the measuring instrument.

4.2 Measuring

Please note the required minimum immersion depth and minimum flow (see chapter 7 TECHNICAL DATA).


The minimum flow can be provided in different ways, e. g.:

- The flow velocity of the water to be measured is sufficient (aeration tank, water pipe, stream)
- Slowly pull the sensor through the water by hand (lake, container), or
- Use a flow aid, e. g. a magnetic stirrer with stirring device (see chapter 8 WEAR PARTS AND ACCESSORIES)

4.3 Storage

Always store the sensor in the calibration vessel at a temperature of 0 to +50 °C. Make sure that the sponge in the calibration vessel is always moist.

Calibration vessel,
OxiCal®-SL



Moisten the sponge:

- Remove the cap (1).
- Take out the sponge (2), wet it, then slightly squeeze it out.
- Reinsert the sponge and close the calibration vessel with the cap.

5 Maintenance, cleaning, replacement

5.1 General maintenance instructions

For your safety

When dealing with the ELY/G electrolyte solution, observe the following safety instructions:



Caution

The ELY/G electrolyte solution irritates eyes and skin. When dealing with the ELY/G electrolyte solution, observe the following points:

- During working activities, always wear suitable protective gloves and protective goggles/face shield.
- If it comes into contact with the skin, rinse thoroughly with water and immediately change contaminated clothing.
- If it comes into contact with the eyes, rinse thoroughly with water and consult a doctor.
- Follow the safety datasheet.



Caution

Before all maintenance activities, disconnect the sensor from the instrument.



Note

Information on how to order wear parts and maintenance accessories can be found in chapter 8 WEAR PARTS AND ACCESSORIES.

5.2 Exterior cleaning

Cleaning agents

Contamination	Cleaning procedures
Lime sediments	Immerse in acetic acid for 1 minute (volume share = 20 %)
Fat/oil	Clean with warm water that contains washing-up liquid

After cleaning, thoroughly rinse with deionized water and recalibrate if necessary.

5.3 Changing the electrolyte and membrane head



General information


Caution

Before starting to work with the sensor, please note the **GENERAL MAINTENANCE INSTRUCTIONS** on page 23.

WTW delivers the sensor ready to operate (see section 3). The electrolyte solution and the membrane head must only be replaced if:


- a calibration error occurs and the membrane is heavily contaminated
- the membrane is damaged
- the electrolyte solution is exhausted
- in case of a leak message by the measuring instrument.

Changing the electrolyte solution and the membrane head




Unscrew the membrane head.


Caution: Electrolyte solution!
For disposal of the membrane head and electrolyte solution, see section 5.6.



Rinse the sensor head with deionized water.




Carefully rub and dry the counter electrode with a lint-free paper towel.




Immerse the sensor head including the counter electrode in RL/G cleaning solution.


Allow to react for 1 to 3 minutes.




Thoroughly rinse the sensor head with deionized water.




Water the counter electrode in deionized water for at least 10 minutes.



Carefully shake off the drops of water.




Fill a new membrane cap with ELY/G electrolyte solution.




Remove any air bubbles by carefully tapping the membrane head. Additionally, you can prevent air bubbles by throwing the first fill away and refilling the membrane head.



Thoroughly rinse the sensor head with electrolyte solution.



Hold the sensor inclined and screw on the membrane head fingertight using a paper towel. Excess electrolyte solution is forced out of the ventilation area.



Check the filling: Inspect the face surface. No air bubbles may be present within the dashed circle (approx. the black area). Air bubbles outside this area do not interfere.



Readiness to measure

Note

For measurements under high pressure the filling must be completely free of air bubbles.

After approx. 30 to 50 minutes, the sensor is ready for operation. Subsequently calibrate the sensor.



Note

If you want to measure very low oxygen concentrations (< 0.5 % saturation), we recommend to let the sensor rest overnight and then calibrate it.

5.4 Cleaning the electrodes




General information

Caution

Before starting to work with the sensor, please note the **GENERAL MAINTENANCE INSTRUCTIONS** on page 23.

Cleaning is only required in cases of slopes that are too small or too large (sensor cannot be calibrated) that cannot be resolved by changing the membrane head and electrolyte solution.

Cleaning the electrodes




Unscrew the membrane head.

Caution: Electrolyte solution!
For disposal of the membrane head and electrolyte solution, see section 5.6.




Rinse the sensor head with deionized water.




Using the rough side of the **wet SF 300** polishing strip, polish off any contamination from the gold working electrode using light pressure.


Caution: Do not use any conventional sandpaper or glass-fiber brushes.




Rinse the sensor head with deionized water.




Wipe the counter electrode with a lint-free paper towel and carefully remove any loose white deposits.




Immerse the sensor head including the counter electrode in RL/G cleaning solution. Allow to react for 1 to 3 minutes.




Thoroughly rinse the sensor head with deionized water.




Water the counter electrode in deionized water for at least 10 minutes.



Carefully shake off the drops of water.




Fill a new membrane cap with ELY/G electrolyte solution.




Remove any air bubbles by carefully tapping the membrane head. Additionally, you can prevent air bubbles by throwing the first fill away and refilling the membrane head.



Rinse the sensor head with electrolyte solution.



Hold the sensor inclined and screw on the membrane head fingertight using a paper towel. Excess electrolyte solution is forced out of the ventilation area.



Check the filling: Inspect the face surface. No air bubbles may be present within the dashed circle (approx. the black area). Air bubbles outside this area do not interfere.

**Note**

For measurements under high pressure the fill must be completely free of air bubbles.

Readiness to measure

After approx. 30 to 50 minutes, the sensor is ready for operation. Subsequently calibrate the sensor.

**Note**

If you want to measure very low oxygen concentrations (< 0.5 % saturation), we recommend to let the sensor rest overnight and then calibrate it.

5.5 Checking the sensor for freedom from zero-current

The sensor is zero-current free. Checking the sensor for freedom from zero-current is only necessary in the case of malfunctions that cannot be remedied by exchanging the electrolyte solution and membrane head or by cleaning the electrodes.

There are two possibilities to check the sensor for freedom from zero-current:

- Measurement in a nitrogen atmosphere (recommended method)
- Measurement in a sodium sulfite solution according to DIN EN 25814/ISO 5814.

**Caution**

If you check the sensor according to DIN EN 25814/ISO 5814, do not leave the sensor in the sodium sulfite solution for more than 2 minutes. Danger of sensor poisoning!

Test criterion

The sensor is OK if the measuring instrument displays < 1 % DO saturation after 2 minutes.

5.6 Disposal



Caution

The ELY/G electrolyte solution irritates eyes and skin. When dealing with the ELY/G electrolyte solution, observe the following points:

- During working activities, always wear suitable protective gloves and protective goggles/face shield.
- If it comes into contact with the skin, rinse thoroughly with water and immediately change contaminated clothing.
- If it comes into contact with the eyes, rinse thoroughly with water and consult a doctor.
- Follow the safety datasheet.

Sensor and membrane head

For disposal, unscrew the membrane head and rinse the sensor and membrane head with water. We recommend disposing of the sensor without the membrane head as electronic refuse. The membrane head may be disposed of with the household refuse.

Electrolyte solution

Disposal according to the safety data sheet.


6 What to do if...

Error symptom	Cause	Remedy
The sensor is in the air and the display shows 0.0 mg/l or 0 % O ₂	<ul style="list-style-type: none"> – No connection between measuring instrument and sensor – Cable defective – No electrolyte in the membrane head 	<ul style="list-style-type: none"> – Check connection between measuring instrument and sensor – Replace and refill the membrane head (see section 5.3)
The sensor cannot be calibrated	<ul style="list-style-type: none"> – Contaminated membrane head – Electrolyte depleted 	<ul style="list-style-type: none"> – Replace and refill the membrane head (see section 5.3). Subsequently, wait for 30 to 50 min and recalibrate.
The sensor still cannot be calibrated after changing the electrolyte and membrane head	<ul style="list-style-type: none"> – Contaminated electrodes or sensor toxification 	<ul style="list-style-type: none"> – Clean the electrodes (see section 5.4)
Leak display appears	<ul style="list-style-type: none"> – Membrane head not screwed on tight enough – Hole in the membrane 	<ul style="list-style-type: none"> – Screw membrane head tighter – Replace and refill the membrane head (see section 5.3)
Incorrect temperature display	<ul style="list-style-type: none"> – Temperature sensor defective 	<ul style="list-style-type: none"> – Return the sensor
Mechanical damage to the sensor		<ul style="list-style-type: none"> – Return the sensor

7 Technical data

General features	Measuring principle	Membrane covered galvanic sensor
	Temperature compensation	IMT compensation (calculated by the measuring instrument)

**Dimensions
(in mm)**



Weight 170 g (with 1.5 m cable)

Materials	Working electrode	Gold
	Counter electrode	Lead
	– Shaft – Connection head – Screwed cable gland – Membrane head	POM
	Membrane	FEP, 13 µm
	Sensor head	Epoxy, PEEK
	Thermistor housing	VA steel 1.4571
	Seals	FPM (Viton)

Connection cable	Lengths	1.5 ... 20 m
	Diameter	6 mm
	Smallest allowed bend radius	Permanent bend: 80 mm Single time or short time bend: 50 mm
	Plug type	Socket, 8 pins

Pressure resistance	Sensor	IP 68 (6 bar)
	Sensor cable	IP 68 (2 bar)
	Plug	IP 67 (when plugged in)

The CelloX 325 meets the requirements according to article 3(3) of the 97/23/EC directive ("Pressure equipment directive").

Measurement conditions



Measuring ranges at 20 °C	0 ... 50 mg/l O ₂ 0 ... 600 % O ₂ saturation 0 ... 1250 mbar O ₂ partial pressure
Temperature range	0 ... 50 °C
Max. allowed overpressure	6·10 ⁵ Pa (6 bar)
Depth of immersion	min. 6 cm max. 20 m (depending on the cable length)
Operating position	any
Approach flow	> 3 cm/s at 10 % measurement accuracy 10 cm/s at 5 % measurement accuracy 18 cm/s at 1 % measurement accuracy

Characteristic data on delivery

Zero signal	< 0.1 % of the saturation value
Response time at 20 °C	t ₉₀ (90 % of the final value display) < 10 s t ₉₅ (95 % of the final value display) < 16 s t ₉₉ (99 % of the final value display) < 60 s
Oxygen own consumption at 20 °C	0.008 µg·h ⁻¹ (mg/l) ⁻¹
Drift	approx. 3 % per month in the operating condition
Working life	min. 6 months with one electrolyte fill

Pin assignment

Plug from the front:



8 Wear parts and accessories

Wear parts and maintenance accessories	Description	Model	Order no.
	Set of exchange membrane caps (3 pieces)	WP 90/3	202 725
	Electrolyte solution	ELY/G	205 217
	Cleaning solution for lead counter electrode	RL/G	205 204
	Polishing film	SF 300	203 680
	Accessory kit, comprising: – 3 exchange membrane caps WP 90 – Polishing film SF 300 – Electrolyte solution ELY/G – Cleaning solution RL/G	ZBK 325	202 706

Accessories	Description	Model	Order no.
	Calibration and storage vessel	OxiCal [®] -SL	205 362
	Magnetic stirrer	Oxi-Stirrer 300	203 810
	Stirring accessory - provides a constant, defined flow of the sensor, in conjunction with the Oxi-Stirrer 300	RZ 300	203 824
	Funnel set - for BOD measurements in Winkler bottles	TS 19	205 710
	Karlsruhe bottle - suitable for BOD measurements	KF 12	205 700
	Fixing ring, recommended for measurements in Karlsruhe bottles	FR 19	205 712
	Flow-through accessory - for pressure-free oxygen measurement with flow-through quantities from 25 to 65 ml/min.	D 201	203 730
	Shaft extension	SVL 325	903 832
	Plastic armoring	A 325/K	903 830
	Battery stirrer for depth measurements - only in conjunction with the A 325/K plastic armoring	BR 325	203 826



Note

For further accessories, refer to the WTW catalog or the Internet.