■ Technical Specifications


Measurement Specifications		
Measurment principle	Energy Dispersive X-ray Fluorescence Analysis Method (EDXRF)	
Measurement sample	Sulfur in Petroleum products such as heavy oil, naphtha, and crude oil, light oil	
Measurement range	0 - 9.9999 %	
Repeatability	15 ppm or less (with a 1 % sulfur sample)	
C/H error correction	± 50 ppm or less per C/H (with a 1 % sulfur sample)	
Lower detection limit	15 ppm or less (three times the standard deviation with a 0 % sample)	
Number of calibration curves	5 lines × 3 sets (Total 15 lines)	
Calibration curve order	Linear or quadratic (both automatic selection and manual settings available)	
Calibration	Calibration made using calibration points: (5 - 20 points)	
Sample requirement	4 - 10 ml	
Measurement time	10 - 600 sec	
Spectrum measurement	Energy Axis: 0 - 10 keV, spectrum analysis to verify instrument preformances.	
External output	USB connect with PC, USB memory	


Ambient Conditions		
Temperature	+ 5 °C ~ + 40 °C (+ 41°F ~ + 104°F)	
Humidity	80% max relative humidity in temperature range + 5 °C \sim + 30 °C (+ 41 °F \sim + 86 °F). Linear decrease to 50% relative humidity in temperature range + 31 °C \sim + 40 °C (+ 88 °F \sim + 104 °F).	

Power and Housing		
Power supply	AC 100 - 240 V ± 10 %, 50/60 Hz	
Power consumption	80 VA	
Dimentions [W x D x H]	230 x 400 x 140 mm (9 x 15.75 x 5.5 in.)	
Weight	9 kg (20 lbs.)	



Dimentional Outlines (Unit : mm)







Please read the operation manual before using this product to assure safe and proper handling of the product.

- The contents of this catalog are subject to change without prior notice, and without any subsequent liability to this company.
- The color of the actual products may differ from the color pictured in this catalog due to printing limitations. • It is strictly forbidden to copy the content of this catalog in part or in full.
- All brand names, product names and service names in this catalog are trademarks or registered trademarks of their respective companies.
- Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

http://www.horiba.com e-mail: info@horiba.co.jp

●HORIBA, Ltd. Head Office 2 Miyanohigashi, Kisshoin Minami-ku, Kyoto, Japan Phone: 81 (75) 313-8123 Fax: 81 (75) 321-5725

 HORIBA (China) Trading Co., Ltd.
 Shanghai Office Beijing Office
Unit D, 1F, Building A, Synnex Room 1801, SK Tower International Park, 1068 Tower 1 No.6 Jia,
West Tianshan Road,
Jianguomenwai Ave. Shanghai, 200335 China Phone: 86 (21) 6289-6060 Fax: 86 (21) 6289-5553

HORIBA Thailand Ltd
393, 395, 397, 399, 401, 403
Latya Road, Somdetchaopraya
405, 10, Ubi Crescent #05-12 Sub-district Klongsan

Lobby B Ubi Techpark

Singapore 408564 Phone: 65 (6) 745-8300 Fax: 65 (6) 745-8155

ingapore) Pte Ltd.
Hanoi Office
Unit 10, 4 Floor, CMC tower,
Duy Tan Street, Dich Vong
Hau Ward, Cau Giay district,
Hanoi, Vietnam
Phone: 84 (4) 3795-8552
Fax: 84 (4) 3795-8553

Chaoyang District, Beijing, 100022 China

Jakarta Office Menara Bidakara 2 Unit 11-04, Jl. Jend. Gatot Subroto

Guangzhou Branch Room 1611/1612, Goldion Digital Network Centar, 138 Tiyu Road East,

Guangzhou, 510620 China Phone: 86 (20) 3878-1883

Fax: 86 (20) 3878-1810

Edison Office 3880 Park Ave., Edison, NJ 08820, U.S.A Phone: 1(732)494-8660 Fax: 1(732)549-5125

 HORIBA Korea Ltd. HORIBA Korea Ltd.
 10, Dogok-Ro, 6-Gil,
 Gangnam-Gu, Seoul,
 135-860, Korea
 Phone: 82 (2) 753-7911
 Fax: 82 (2) 756-4972

Spain Branch PAE Neisa Norte Ed. II, Avenida Vadelaparra,

Madrid Spain Phone: 34 (91) 661 7987 Fax: 34 (91) 661 6658

rporated Irvine Office 9755 Research Drive, Irvine, CA 92618, U.S.A. Phone: 1 (949) 250-4811 Fax: 1 (949) 250-0924

 HORIBA India Private
 Limited
 Delhi Office
 246, Okhla Industrial Estate,
 Phase 3 New Delhi - 110020,
 India Industrial Estate, ●HORIBA JOBIN YVON SAS HORIBA JOBIN YVON GmbH
Haupt-Str. 1,82008
HoriBA JOBIN YVON SrI
Via Cesare Pavese 19/21, 16-18, rue du Canal, 91165 Longjumeau Cedex, 200900 Opera, Mirano, Italy Phone: 33 (0) 1 69 74 72 00 Phone: 49 (89) 462 3170 India Phone: 91 (11) 4646-5000

●HORIBA UK Ltd. 2 Dalston Gardens, Stanmore, Middx HA7 1BQ GREAT Phone: 44 (20) 8204 8142



Sulfur-in-Oil Analyzer

SLFA-60



072022

Bulletin:HRE-3937A

SLFA-60 for a new generation of petroleum products

HORIBA introduces the new standard of transportable sulfur-in-oil analyzers, the SLFA-60. This instrument introduces new software and hardware features to meet the growing changes in the petroleum industry.

The instrument has expanded storage of calibration curves and data can be exported using USB output.

The measurement range has increased to 0-9.9999 wt% to cover high sulfur crudes and shale oil markets.

Simple operation

Easy maintenance

Lightweight

Compact

Robust construction


Data output

The printout is available in an 80 mm wide format for easy comprehension.

HORIBA

Safety mechanism

The SLFA-60 has a protective membrane covering the cell window to prevent the detector and X-ray tube from accidental sample leakage. This protective membrane unit is simple to assemble and replace.



Cross section of sample cell and detector

Large screen display for easy viewing

The screen will display real-time data to check the measurement conditions.

USB memory

Your measurements can be recorded three different ways; by printout, exported to a USB memory device, or exported to an external PC through a USB interface, making it possible track and analyze the information throughout the lifetime of the unit.

Measurement Procedure

Pour the sample into the sample cell

Place the sample cell on the sample holder

Set to the measurement condition

Press the "MEAS" button to start the measurement

Instrument displays the results and data output


Calibration

New Software features allow up to 15 separate calibration curves. There are three sets and each set represents 5 separate calibration curves.

The Software also allows the users to choose between linear or quadratic curves. Calibration curves are restored manually without having to recalibrate as long as coefficients value/calibration data are on hand.

Original Sample Cell

To ensure accuracy and reliability of the analysis, HORIBA has maintained its original sample cell. By using the sample jig tool provided, you can easily seal the sample so that it is leak free.



Expanded Measurement Range (0~9.9999wt%)

Sulfur-in-Oil Analyzer

SLFA-60

: 2013/06/17 09:12

: 10 sec

: Unfinished

0,5434

1,0039

This new model can measure a wider range of sulfur content. It has an expanded range to measure from 0-9.9999 wt% sulfur, due to the higher sulfur concentrations of crude and shale oil markets.

Large printouts

Printouts show important information, including sample ID, X-ray spectrum, date and time, measurement average value, standard deviation and calibration curve graph.

Measure Time

E INT (CPS)

K(CORR COEF)

*Calibration-Autorate AL Range Set AL Curve # easure Time epeat	: 2013/06/11 17:19 : 2 : 1 : 100 sec : 1 times
um of STD alibration Degre	: 4
TD #01 1/01	0,0000 % K 0,0917
TD #02 1/01	1,0200 % K 0,5452
TD #03 1/01	2,0400 % K 1.0322
TD #04 1/01	3,9300 % K 2.0536
= A*K^2 + B*K + = = :- ange : 0,0000	-0. 16287 2. 35238 -0. 21424
1 0,0000 0. 2 1,0200 0. 3 2,0400 1. 4 3,9300 2.	K SUB .0917 (0,0000) .5452 (0,0002) .0322 (0,0004) .0536 (0,0002)
<u> </u>	
	1

